


# Centration Chart

## Endless Steady Progressive



### PLEASE NOTE:

This chart will not work as a measurement tool unless printed at exactly 1 to 1 scale. Be sure that your print options are set to page scaling: none. DO NOT select "fit to printable area".

1 cm




### DEFAULT PERSONALIZATION PARAMETERS

Wrap	Panto	Vertex
5°	12°	14 mm

### ENGRAVING INDEX


M = Material DC = Design Code ADD = Addition Power

Product	Design Code
Endless Steady	ES
Endless Steady Distance	ESd
Endless Steady Intermediate	ESi
Endless Steady Near	ESn



Endless Steady Progressive lenses are open format designs, compatible with any spherical lens blank. Drop = 4 mm. Recommended MFHs are 14, 15, 16, 17, and 18 mm (infinitesimal steps). Contact your laboratory for more information.

# Centration Chart Endless Drive Progressive



## PLEASE NOTE:

This chart will not work as a measurement tool unless printed at exactly 1 to 1 scale. Be sure that your print options are set to page scaling: none. DO NOT select "fit to printable area".

1 cm

## DEFAULT PERSONALIZATION PARAMETERS




Wrap	Panto	Vertex
5°	12°	14 mm

## ENGRAVING INDEX


M = Material DC = Design Code ADD = Addition Power

Product	Design Code
Endless Drive Progressive	EDr

Keep 8 mm between the fitting cross and the top of the frame to ensure the wearer receives the maximum benefit from the night vision zone.



# Centration Chart Endless Sport Progressive



## PLEASE NOTE:

This chart will not work as a measurement tool unless printed at exactly 1 to 1 scale. Be sure that your print options are set to page scaling: none. DO NOT select "fit to printable area".

1 cm




## DEFAULT PERSONALIZATION PARAMETERS

Wrap	Panto	Vertex
15°	12°	14 mm

## ENGRAVING INDEX


M = Material DC = Design Code ADD = Addition Power

Product	Design Code
Endless Sport Progressive	ESp



# Centration Chart

## Essential Steady Progressive



**PLEASE NOTE:**




This chart will not work as a measurement tool unless printed at exactly 1 to 1 scale. Be sure that your print options are set to page scaling: none. DO NOT select "fit to printable area".

1 cm

**ENGRAVING INDEX**


M = Material    DC = Design Code    ADD = Addition Power

Product	Design Code
Essential Steady	E
Essential Steady Distance	Ed
Essential Steady Intermediate	Ei
Essential Steady Near	En



Essential Steady Progressive lenses are open format designs, compatible with any spherical lens blank. Drop = 4 mm. Recommended MFHs are 14, 15, 16, 17, and 18 mm. Contact your laboratory for more information.

# Centration Chart Endless Office Occupational



## PLEASE NOTE:

This chart will not work as a measurement tool unless printed at exactly 1 to 1 scale. Be sure that your print options are set to page scaling: none. DO NOT select "fit to printable area".

1 cm

## DEFAULT PERSONALIZATION PARAMETERS

Wrap	Panto	Vertex
5°	12°	14 mm

## ENGRAVING INDEX

M = Material DC = Design Code ADD = Addition Power

Product	Design Code
Endless Office 1.3 m	EO1
Endless Office 2 m	EO2
Endless Office 4 m	EO4

